



TECNODECK ARCHITECTONIC PROFILES













© Tecnodeck ALL RIGHTS RESERVED





Tecnodeck® TECNODECK Architectonic Profiles

Basic mounting rules

. Tecnodeck profiles must always work together with metal reinforcement profiles.

. The fixation of Tecnodeck profiles must be made to the metal reinforcement profiles and never to the composite profiles. All holes in WPC must be to pass and having a larger diameter than the screw hole that passes through it, so that the screw will never be a constraint for WPC. The composite hole diameter should be larger than the screw diameter at least 2mm/profile meter.

The tightening of the screws at the composite should never crush the composite profile and must allow the free movement of the profile.



 $Ø_{\rm H}$ (mm) = 2 x L (m) + $Ø_{\rm S}$ (mm)

. A distance between the top ends of a profile and rigid obstacles is required (between walls or similar) at the rate of 1mm / ml.

. Please validate the fixations with Tecnodeck technical department.

. Any type of assembly not specified, must be previously approved by Tecnodeck.

. For quantities, bespoke profiles are possible under request.

L = 1,5M L = 2M L = 2,50m L = 3m L = 3,50m L = 4m L = 5m Profile Position DEFLETION (mm) L/f 0.1 L/15.000 0.2 /10.000 0,6 L/4.165 L/3.000 2 L/1.750 4 L/1.000 17 1/294 1 ALU 68 x 68 0,1 L/15.000 L/10.000 0,6 L/4.165 L/3.000 2 L/1.750 4 L/1.000 17 0,2 1 1/29 2 9 L/390 15 L/265 L/1250 5 L/600 /300 L/2000 NPC 85x30 + ALU 38x20 \bigcirc L/1500 2 L/1000 4 L/625 L/375 15 L/235 1 8 2 L/750 L/500 L/250 4 10 2 1/750 3 1/665 8 1/300 0 WPC 30x22 + ST 20x10x1 3 L/500 5 L/400 11 L/230 0 L/375 L/250 4 8 L/f = 2.500/1.250 = 2mm2.500 mm 2 mm

. Distances between supports:



When fixing with screws profiles:



- Inner structural profile;
- Needs a 1mm/m gape betwen top profiles;



- Use a inner bushing to prevent smashing wpc profile;
- Protect the wpc with oversize washers



Tecnodeck[®] TECNODECK Architectonic Profiles

- Consider wpc hole diameter at least 7mm more than bushing outside diameter;
- Structural profile hole diameter equal to bushing outside diameter.
- All these parameters must be considered in any WPC profile, such as 85x85, 85x30 and 30x22.



• Some different examples:

• If in any doubt, please contact TECNODECK.



3 Impasse Lotissement Berthé 97 200 FORT DE FRANCE Tél : 05 96 030 777